

ASSEMBLING INSTRUCTIONS

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE. DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.



STEP 1	CHECK YOUR HARDWARE	QTY	
	SCREW #9 X 1 1/2"	20 PCS	
	WOOD DOWEL M6 X 25	12 PCS	
	STICKER Ø18	18 PCS	
TOOLS REQUIRED :			
	SCREW DRIVER		HAMMER
<p>STEP 2</p> <p>WOOD DOWEL M6 X 25</p> <p>Detail A</p> <p>Detail A</p>	<p>STEP 3</p>	<p>STEP 5</p>	<p>STEP 10</p> <p>Detail A</p>
<p>STEP 4</p>	<p>STEP 6</p>	<p>STEP 8</p>	<p>STEP 9</p>
<p>STEP 7</p>	<p>STEP 10</p> <p>Detail A</p>	<p>STEP 10</p> <p>Detail A</p>	<p>STICKER Ø18</p> <p>Detail A</p>



DO NOT RETURN TO THE STORE
Individual stores do not stock parts.

Need parts or assistance?
1-833-562-4730

drop us an e-mail
support@momentumwarranty.com
For prompt, reliable service, please have your manual ready.